

PG-9182PT

Powerline Ethernet Adapter

User Manual



Preface

This manual provides information related to the installation and operation of this device. The individual reading this manual is presumed to have a basic understanding of telecommunications terminology and concepts.

If you find the product to be inoperable or malfunctioning, please contact technical support for immediate service by email at INT-support@comtrend.com

For product update, new product release, manual revision, or software upgrades, please visit our website at <http://www.comtrend.com>

Important Safety Instructions

With reference to unpacking, installation, use, and maintenance of your electronic device, the following basic guidelines are recommended:

- Do not use or install this product near water, to avoid fire or shock hazard. For example, near a bathtub, kitchen sink or laundry tub, or near a swimming pool. Also, do not expose the equipment to rain or damp areas (e.g. a wet basement).
- To safeguard the equipment against overheating, make sure that all openings in the unit that offer exposure to air are not blocked.
- Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightening. Also, do not use the telephone to report a gas leak in the vicinity of the leak.



WARNING

- Disconnect the PLC from the power source before servicing
- For indoor user only
- Do NOT open the casing
- Do NOT use near water
- Do NOT insert sharp objects into the adapter's socket
- Socket maximum output is 15A

Power Specifications:

I/P : 100-125Vac, 50/60Hz, 15A

O/P : 100-125Vac, 50/60Hz, 15A

Copyright

Copyright©2019 Comtrend Corporation. All rights reserved. The information contained herein is proprietary to Comtrend Corporation. No part of this document may be translated, transcribed, reproduced, in any form, or by any means without prior written consent of Comtrend Corporation.

NOTE: This document is subject to change without notice.

Protect Our Environment

This symbol indicates that when the equipment has reached the end of its useful life, it must be taken to a recycling centre and processed separate from domestic waste.

The cardboard box, the plastic contained in the packaging, and the parts that make up this PLC can be recycled in accordance with regionally established regulations. Never dispose of this electronic equipment along with your household waste; you may be subject to penalties or sanctions under the law. Instead, please be responsible and ask for disposal instructions from your local government.


Table of Contents

CHAPTER 1 PRODUCT INFORMATION.....	4
1.1 FRONT PANEL AND LED INDICATORS.....	4
1.2 SIDE PANEL.....	5
1.3 BOTTOM PANEL	5
1.4 QUICK INSTALL GUIDE	6
1.5 HOW TO UNDERSTAND THE COVERAGE LED COLORS.....	10
CHAPTER 2 G.HN/POWERLINE SETUP	11
2.1 LOGGING IN.....	11
CHAPTER 3 G.HN INTERFACE	12
3.1 BASIC CONFIGURATION	12
3.2 NDIM CONFIGURATION	13
3.3 ENCRYPTION CONFIGURATION VIA WEB UI.....	13
CHAPTER 4 IP INTERFACE.....	14
4.1 IP CONFIG	14
CHAPTER 5 ETHERNET INTERFACE	16
CHAPTER 6 DEVICE INTERFACE.....	17
6.1 HARDWARE INFORMATION	17
6.2 SOFTWARE INFORMATION	17
6.3 SECURITY	18
6.4 SW UPDATE	18
6.5 HTTP SW UPDATE.....	18
CHAPTER 7 MULTICAST INTERFACE.....	19
7.1 MCAST CONFIGURATION	19
CHAPTER 8 QOS MENU	21
8.1 QoS CONFIGURATION.....	21
CHAPTER 9 VLAN INTERFACE	23
9.1 VLAN CONFIGURATION	24
CHAPTER 10 G.HN SPECTRUM INTERFACE	25
10.1 NOTCHES.....	25
CHAPTER 11 LOG FILE INTERFACE.....	26
11.1 LOG FILE	26
CHAPTER 12 TR069	27
CHAPTER 13 ADVANCED INTERFACE	29

The setup images used in this manual are for reference only. The contents of these images may vary according to firmware version. The official image contents are based on the newest firmware version.

Chapter 1 Product Information


1.1 Front Panel and LED indicators




LED	Color	Mode	Description
Power LED 	Green	On	The Adapter is powered on.
	Off	Off	The Adapter is powered off or faulty.
Connection LED 	Green	On	The current connection (line rate) is more than 40Mbps.
	Orange	On	The current connection (line rate) is between 5Mbps and 40Mbps.
	Red	On	The current connection (line rate) is less than 5Mbps.
	Off	Off	An Adapter connection does not exist.
Security LED 	Green	On	The Adapter is secure (it has received or generated network keys).
		Blinking	The Adapter is in the process of being secure.
	Off	Off	The Adapter is not secure.
Ethernet LED 	Green	On	An Ethernet LAN connection is established.
		Blinking	Data over the Ethernet LAN connection is being transmitted.
	Off	Off	An Ethernet LAN connection is not established.

1.2 Side Panel



Item Name	Description
Security 	Push the button for 2-5 seconds to pair the devices and get a random domain name and password.
Reset	Press more than 10 seconds (until all four LED's are ON) and release: a factory reset is performed.

1.3 Bottom Panel



1.4 Quick Install Guide


A

Understanding Your Powerline Adapter



Security Button

Enables Device Synchronization in Secure Mode




Reset Button

Press for more than 10 seconds for Factory Reset



LED Icons

Descriptions are provided below



Ethernet Port

LED	Color	Mode	Description
Power LED 	Green	On	The Adapter is powered on.
	Off	Off	The Adapter is powered off or faulty.
Connection LED 	Green	On	The current connection (line rate) is more than 40Mbps.
	Orange	On	The current connection (line rate) is between 5Mbps and 40Mbps.
	Red	On	The current connection (line rate) is less than 5Mbps.
	Off	Off	An Adapter connection does not exist.
Security LED 	Green	On	The Adapter is secure (it has received or generated network keys).
		Blinking	The Adapter is in the process of being secure.
	Off	Off	The Adapter is not secure.
Ethernet LED 	Green	On	An Ethernet LAN connection is established.
		Blinking	Data over the Ethernet LAN connection is being transmitted.
	Off	Off	An Ethernet LAN connection is not established.

Initial Powerline Adapter Setup

NOTE: A minimum of two G.hn Powerline Adapters are required.


→ If you are setting up a G.hn Powerline network for the first time, then follow the below steps.


→ If you are adding to an existing G.hn Powerline network, then skip to Steps 3-4.

1. Plug one Powerline Adapter into a power outlet near your Network Device (Modem, Router, or Access Point).





For maximum performance, please plug the Powerline Adapter directly into the wall outlet. Do not plug into a power strip or surge protector, as network performance could degrade significantly.


2. Connect the Powerline Adapter to your Network Device (Modem, Router, or Access Point) with an Ethernet (RJ-45) cable. Wait 10 seconds for the **Ethernet LED**  to light up **GREEN**, which indicates a connection is established. A flashing **GREEN** light indicates that the device is sending data.



C





Device Connection





3. Plug the **additional Powerline Adapter** into a power outlet near the Internet-enabled device (ex. TV, PC, STB, DVR, etc.).
4. Connect this Powerline Adapter to the Internet-enabled device (ex. TV, PC, STB, DVR, etc.). with an Ethernet (RJ-45) cable. The **Connection LED**  and **Ethernet LED**  on the front of both Powerline Adapters should be **GREEN**, which represents a strong connection.



D

Pairing the Powerline Adapters


5. Press the **Security Button** on one Adapter until you see the **Security LED**  start blinking **GREEN**. Then press the **Security Button** on the second Adapter until you see the **Security LED**  start blinking **GREEN**. The **Security LED**  and the **Connection LED**  should be solid **GREEN** on both Adapters when they are successfully paired.

Note: If you are adding to an existing G.hn Powerline network, then press the **Security Button** on any Adapter in the existing G.hn Powerline network until you see the **Security LED**  start blinking **GREEN**. Then press the **Security Button** on the Powerline Adapter you are adding until you see the **Security LED**  start blinking **GREEN**.. The **Security LED**  and the **Connection LED**  will light up **GREEN** on all adapters within the G.hn Powerline network.

6. Repeat Steps 3 to 4 to add additional Powerline Adapters. Please note that up to 16 devices can be connected within a Powerline G.hn Network.





You Have Successfully Set Up Your G.hn Powerline Network!




Troubleshooting

The following information should help you diagnose basic setup or installation problems.

Connection LED  is OFF: The **Connection LED** shows that the Powerline Adapter is connected to the G.hn Network. If the indicator is off, then plug both Powerline Adapters that you are attempting to pair into power outlets that are located within the same room. The **Connection LED** should light up **GREEN**. If not, then press the **Reset Button** on each adapter for more than 10 seconds. Afterwards, you can plug the units back into their original location.

Ethernet LED  is OFF: If the **Ethernet LED** fails to light up, check that the LAN port of the Powerline Adapter is connected firmly to the LAN port of the other device. To check the condition of the Ethernet cable, use another cable to test the same connection.

Security LED  is OFF: If the **Security LED** is off, then it means the Powerline Adapter is not securely paired. Press the **Security Button** on the Powerline Adapter for 3 seconds until you see the **Security LED** start flashing **GREEN**. Repeat this on the other Powerline Adapter. The **Security LED** and the **Connection LED** will light up **GREEN** on both adapters. This means the adapters are now securely paired and have a strong connection.

To join an existing G.hn Powerline network, press the **Security Button** on any Powerline Adapter in the existing G.hn Powerline network for 3 seconds until you see the **Security LED** start flashing **GREEN**. Then press the **Security Button** on the **additional** Powerline Adapter. The **Security LED** and the **Connection LED** will light up **GREEN** on both adapters.

*If you have tried the above and are still experiencing problems, you can reset all devices to factory default by pushing the **Reset Button** for more than 10 seconds (until all the LEDs of the device blink).

1.5 How to understand the COVERAGE LED colors

The COVERAGE LED displays quality of the network and provides important information that will provide solutions to common questions, such as why a High Definition (HD) movie is not showing or shows with pixels. The COVERAGE LED indicator will vary its color depending on the estimated speed of the Powerline connection. The speed is measured in Megabits Per Second (Mbps).

Color	Information
RED	The current connection has low quality, basic Internet activities ex. 5Mbps are possible but the Powerline is unable to transmit either a Standard Movie or High Definition (HD) Movie.
ORANGE	The current connection has good quality and Internet activities ex. greater than 20Mbps and less than 40Mbps to transmit Standard Movie and HD Movie.
GREEN	The current connection has excellent quality and Internet activities ex. greater than 40Mbps to transmit multiple Standard Movies and HD Movies.

Chapter 2 G.hn/Powerline Setup

PG-9182PT uses DHCP mode. It means PG-9182PT has to get IP address via DHCP server. You should check what IP address is assigned to PG-9182PT via your DHCP server and configure you PC IP address according to the IP address that was assigned to PG-9182PT.


2.1 Logging In

Perform the following steps to login to the web user interface.

STEP 1: Start the Internet browser and enter the default IP address for the device in the Web address field. For example, if the default IP address is 192.168.0.5, type <http://192.168.0.5>

STEP 2: A dialog box will appear, such as the one below. Input the default Authentication Password.

Authentication Password: **admin**

The screenshot shows a web browser window displaying the 'PG-9182PT Web Configuration' page. On the left is the 'COMTREND' logo. The main content area is titled 'PG-9182PT Web Configuration' and contains an 'Authentication' section. This section has a message: 'This unit is password protected. Please enter the correct password to access the web pages'. Below the message is a label '•Password' followed by a password input field with five dots. At the bottom right of the authentication box are 'Ok' and 'Cancel' buttons.

Click **OK** to continue.

Note:

The Factory Reset password is: **betera**

Chapter 3 G.hn Interface

PG-9182PT Web Configuration
[Log Out](#)

[G.hn](#)
[IP](#)
[Ethernet](#)
[Device](#)
[Multicast](#)
[QoS](#)
[VLAN](#)
[G.hn spectrum](#)
[Log file](#)
[TR069](#)
[Advanced](#)

Basic settings

- MAC address c8:d1:2a:c3:23:2a
- Device ID 1
- Domain Name jD5LTszbGEfJJJuFEnk7q2bwtnzYTHH6
- Force node Type AUTOMATIC
- Node type* DOMAIN_MASTER

* Node type change can take some time, please refresh page to update state

Ok Cancel

- G.hn profile PLC 100 MHz with MIMO

Ok Cancel

Neighboring Domain Interference Mitigation (NDIM)

- NDIM mode AUTOMATIC
- Domain ID (DOD) 11

Ok Cancel

Encryption Configuration

- Encryption is ENABLED
- Pairing password ****

Change Cancel

- Automatic configuration*: PAIR UNPAIR

* Pairing can take some time, please refresh page to update state

Available Connections

Device ID	MAC Address	Phy Tx (Mbps)	Phy Rx (Mbps)
Empty list			

3.1 Basic Configuration

- **MAC Address** Displays the MAC address of the device.
- **Device ID** Device ID of this node.
- **Domain Name** string of all nodes in the network.
- **Force node Type** force the modem to have a particular role (END POINT or DOMAIN MASTER)
- **Node Type**
Shows the current status of the device.
- **G.hn profile** of all nodes in the network: selecting which G.hn profile must be applied to the network (PLC 50MHz, PLC 50MHz with MIMO, PLC 100MHz, COAX 100MHz and PHONE 100MHz).

3.2 NDIM Configuration

- **NDIM mode** set to Automatic for enabling automatic DOD selection functionality and set to Manual for manual configuration of DOD.
- **Domain ID (DOD)** manually set the DOD number from 1 to 15 to use a different preamble seed than the default 0.

3.3 Encryption Configuration via WEB UI

- **Pairing Password** used for authentication. Write a custom password to manually create a secure domain.

Available Connections

- In this tab table, all the available **G.hn connections** are presented. Remote node DID and MAC address, transmission and reception physical speeds.

Chapter 4 IP Interface

PG-9182PT Web Configuration

Log Out

[G.hn](#)
[IP](#)
[Ethernet](#)
[Device](#)
[Multicast](#)
[QoS](#)
[VLAN](#)
[G.hn_spectrum](#)
[Log file](#)
[TR069](#)
[Advanced](#)

IPv4 configuration*

DHCP enabled

NO ▾

IPv4 address / netmask

192.168.0.5

 /

255.255.255.0

Default Gateway

192.168.0.5

DNS

192.168.0.5

Additional address #1

0.0.0.0

 /

0.0.0.0

Additional address #2

0.0.0.0

 /

0.0.0.0

*All changes except the DNS server will have effect after system boot

Ok

Cancel

IPv6 configuration*

DHCP enabled

NO ▾

IPv6 address / prefix

0000:0000:0000:0000:0000:0000:0000:0000

 /

0

Default Gateway

0000:0000:0000:0000:0000:0000:0000:0000

DNS

0000:0000:0000:0000:0000:0000:0000:0000

Additional address #1

0000:0000:0000:0000:0000:0000:0000:0000

 /

0

Additional address #2

0000:0000:0000:0000:0000:0000:0000:0000

 /

0

Additional address #3

0000:0000:0000:0000:0000:0000:0000:0000

 /

0

Additional address #4

0000:0000:0000:0000:0000:0000:0000:0000

 /

0

IPv6 link-local address

fe80:0000:0000:0000:cad1:2aff:fec3:232a

 /

128

IPv6 SLAAC address

0000:0000:0000:0000:0000:0000:0000:0000

 /

0

*All changes except the DNS server will have effect after system boot

Ok

Cancel

NTPv4/v6 client configuration

NTPv4/v6 client enabled

NO ▾

Resynchronization time (minutes)

30

NTP IPv4/v6 address

clock.isc.org

Ok

Cancel

4.1 IP config

In the **IP configuration** tab of one G.hn node, the IPv4 and IPv6 settings can be read and changed.

IPv4 subsection:

- **DHCPv4 enabled:** in the case of choosing "NO" IP configuration in the following parameters, the IPv4 Address, Subnet Mask, Default Gateway and DNS should be configured; fill these fields in. In the case of choosing "YES" they will be filled automatically when configuration is received from the DHCPv4 server.
- **IPv4 address/netmask:** IPv4 address / netmask of this device.
- **Default Gateway:** IPv4 gateway to connect the device to other LAN segments.
- **DNS:** Domain Name Server IP (IPv4).
- **Additional address #1/2:** additional fixed IPv4 addresses that will always be configured at boot time.


IPv6 subsection:

- **DCHPv6 enabled:** in the case of choosing "**NO**" IP configuration in the following parameters, the IPv6 Address, prefix, Default Gateway and DNS should be configured; fill these fields in. In the case of choosing "**YES**" they will be filled automatically when configuration is received from the DHCPv6 server.
- **IPv6 Address / prefix:** IPv6 address / prefix of the device to read the node's DHCPv6 address in case the DHCPv6 is enabled.
- **Default Gateway:** IPv6 gateway to connect the node to other LAN segments.
- **DNS:** Domain Name Server IP (IPv6).
- **Additional address #1/2/3/4:** additional fixed IPv6 addresses that will always be configured at boot time.
- **IPv6 Link-Local Address:** to read the node's Link Local address.
- **IPv6 SLAAC address:** IPv6 address, automatically obtained by means of the SLAAC mechanism.

NTPv4/v6 subsection:

- **NTPv4/v6 client enabled:** Enable/disable NTP client.
- **Resynchronization time:** Configure re-synchronization interval time in minutes.
- **NTP IPv4/v6 address:** Hostname or IP (IPv4 or IPv6) of NTP server.

Chapter 5 Ethernet Interface



PG-9182PT Web Configuration

Log Out

[G.hn](#)
[IP](#)
[Ethernet](#)
[Device](#)
[Multicast](#)
[QoS](#)
[VLAN](#)
[G.hn spectrum](#)
[Log file](#)
[TR069](#)
[Advanced](#)

Ethernet

External Interfaces:

Interface	Speed	Duplex	Interface Type	Mode	Internal PHY	Link
ETHB	100	FULL_DUPLEX	SGMII	MAC	NO	YES

Powersaving

- Inactivity detection mode Disabled
- Inactivity time(s)

Ok Cancel

The Ethernet table shows the status & Info of the Ethernet interface; including Interface, Speed, Duplex, Interface Type, Mode, Internal PHY & Link.

Powersaving

Ethernet powersaving can be disabled, enabled by Ethernet link or enabled by Ethernet activity; idle timer can be configured as well.

Chapter 6 Device Interface

COMTREND

PG-9182PT Web Configuration
[Log Out](#)

[G.hn](#)
[IP](#)
[Ethernet](#)
[Device](#)
[Multicast](#)
[QoS](#)
[VLAN](#)
[G.hn_spectrum](#)
[Log file](#)
[TR069](#)
[Advanced](#)

Hardware information

•Device name	PG-9182PT
•Device description	G.hn 2000 Powerline Pass-Thru Adapter
•Device manufacturer	Comtrend
•Serial number	1849083XXF-BE000139
•MAC address	c8:d1:2a:c3:23:2a
•HW version	3_0

Software information

•FW version	PG-9182PT-78R619111CTU-C01_R02
•System uptime	0 days, 0h 42m 16s

Security

•New Configuration password

[Ok](#)
[Cancel](#)

SW update

•Status	Ready: initial status
•Protocol	<div>FTP</div>
•Server IPv4/v6	<input type="text"/>
•FTP User	<input type="text"/>
•FTP Password	<input type="password"/>
•OSUP Filename	<input type="text"/>

[Ok](#)
[Cancel](#)

HTTP SW update

•Upgrade file:

[Choose File](#)
No file chosen

[Ok](#)
[Cancel](#)

6.1 Hardware information

In this tab, basic information such as MAC Address and Serial Number of the selected node is shown.

6.2 Software information

Shows the FW version and system uptime.

6.3 Security

The nodes in the network: to change the configuration password string from the default ("admin") to another; decided by the user.

6.4 SW update

Current loaded firmware version is shown. Any flash section can be upgraded; the first flash section should be selected and after clicking on the "**OK**" button the corresponding file should be chosen. Usually, a reboot should be performed afterwards to make sure the changes are effective.

The protocol is by FTP client or TFTP client. L2 is proprietary and is reserved for future use.

6.5 HTTP SW update

STEP 1: Enter the path and filename of the firmware image file in the **Software File Name** field or click the Browse button to locate the image file.

STEP 2: Click the **OK** button once to upload and install the file.

NOTE1: The update process will take about 2 minutes to complete. The device will reboot and the browser window will refresh to the default screen upon successful installation. It is recommended that you compare the **Software Version** on the [Device Interface](#) screen with the firmware version installed, to confirm the installation was successful.

NOTE2: The Power LED indicates the status of firmware update progress. Please **DO NOT** power off the device when Power LED is flashing or the device will be damaged.

Chapter 7 Multicast Interface

PG-9182PT Web Configuration Log Out

COMTREND

[G.hn](#)
[IP](#)
[Ethernet](#)
[Device](#)
[Multicast](#)
[QoS](#)
[VLAN](#)
[G.hn_spectrum](#)
[Log file](#)
[TR069](#)
[Advanced](#)

Multicast Configuration*

- IGMP Snooping YES ▾
- MLD snooping NO ▾
- IGMP/MLD broadcast report NO ▾
- IGMP/MLD broadcast report mode 0 ▾
- Filter unknown multicast traffic YES ▾
- IGMP Multicast ranges:

Minimum IP address			Maximum IP address		
224	0	0.0	239	254	255.255
0	0	0.0	0	0	255.255
0	0	0.0	0	0	255.255
0	0	0.0	0	0	255.255

Ok Cancel

Broadcast suppression

- Broadcast xput limit (Mbps) 2

Ok Cancel

7.1 MCAST Configuration

In the **MCAST Configuration** tab of "My Network", **IGMP snooping and MLD** features can be enabled or disabled. Also, IGMP multicast IP addresses ranges which the G.hn PLC network will sniff; can be configured.

- **IGMP Snooping**: Enable or Disable.
- **MLD Snooping**: Enable or Disable.
- **IGMP/MLD broadcast report (allowed)**: set to NO for enabling reports dropping until the video source is detected, this is a recommended setting when IGMP/MLD is enabled. Set to YES for broadcasting reports until the video source is detected; this implies the multicast video stream is sent as broadcast and it is the recommended state when IGMP/MLD is disabled.
- **IGMP/MLD broadcast report mode**: Report broadcast forwarding behavior when the MCAST.GENERAL.REPORT_BROADCAST_ALLOWED is enabled.
 - If 0 then broadcast reports only when the video source is unknown.
 - If 1 then broadcast reports always.
 - If 2 then broadcast reports always if IGMPv3 and only when video source is unknown in others.

The term 'video source' refers to the node whose Ethernet port is connected directly to the Home Gateway.
- **Filter unknown multicast traffic**: Enables the Multicast Filtering feature.
 If enabled, all the unsolicited multicast traffic will be blocked.
 In IPv4 multicast traffic, only the traffic between the IP ranges defined in the MCAST.GENERAL.IGMP_IP_RANGES_DEF and the packets are unsolicited, these packets will be dropped.

Warning: This feature implies a higher CPU load, so it is advisable to enable it only in the Video Source.
Only 100 Kbps of broadcast traffic could be managed in this mode.

IGMP Multicast ranges configuration: 4 multicast IP address ranges can be configured defining the minimum and maximum IP addresses of each range. Only multicast traffic within these ranges will be processed.

Broadcast Suppression: Maximum throughput allowed without suppressing broadcast traffic. The accuracy of this parameter depends on size of packets (big packets -> more accuracy). Value 0 deactivates this functionality.

Chapter 8 QoS Menu

[G.hn](#)
[IP](#)
[Ethernet](#)
[Device](#)
[Multicast](#)
[QoS](#)
[VLAN](#)
[G.hn spectrum](#)
[Log file](#)
[TR069](#)
[Advanced](#)

PG-9182PT Web Configuration Log Out

COMTREND

QoS Configuration

QoS criterion DSCP

Type of frame Ethernet frame

Packet detection 1 None

Offset 0

Bitmask 0x0000

Pattern 0x0000

Packet detection 2 None

Offset 0

Bitmask 0x0000

Pattern 0x0000

Packet classification

•Default prio 0

•TCP Ack Class in IPv4 0 NO

•TCP Ack Class in IPv6 0 NO

•ARP Class 0 NO

DSCP Class

0	0	0	0	0	0	0	0
1	1	1	1	1	1	1	1
2	2	2	2	2	2	2	2
3	3	3	3	3	3	3	3
4	4	4	4	4	4	4	4
5	5	5	5	5	5	5	5
6	6	6	6	6	6	6	6
7	7	7	7	7	7	7	7

PC	Offset	Bitmask	Pattern	Priority
Rule 1	0	0x0000	0x0000	0
Rule 2	0	0x0000	0x0000	1
Rule 3	0	0x0000	0x0000	2
Rule 4	0	0x0000	0x0000	3
Rule 5	0	0x0000	0x0000	4
Rule 6	0	0x0000	0x0000	5
Rule 7	0	0x0000	0x0000	6
Rule 8	0	0x0000	0x0000	7

Ok Cancel

8.1 QoS Configuration

In the **QoS** configuration tab, the packet classifier can be managed to define a QoS rule for incoming Ethernet traffic, and assign a priority to be used in the G.hn network. Press the "**Ok**" button for loading the newly configured settings:

- **QoS CRITERION:** a general criterion can be chosen among "None" (no QoS), "Custom" and "802.1p".
- **Type of Frame:** with this parameter the type of Ethernet traffic being transmitted by the G.hn network should be selected. Based on this parameter, the internal offsets in the system are adjusted. In the QoS tab, Ethernet frame offsets should be set **counting number** as they appear in the sniffer SW (for instance, the same field will be in a different position if normal Ethernet frames or 802.1Q tagged frames exist).

- **Packet detection 1:** first packet detection rule can be configured (offset, bitmask and pattern). Packets which accomplish it will be sent to the classification module.
- **Packet detection 2:** if second packet detection is also enabled, both, first and second detection criteria must be accomplished to pass packets to the classification module.
- **Packet classification:** up to 8 classification rules can be defined in this section for packets which have previously been correctly detected. For 802.1p only priorities can be managed, offset, bitmask and pattern are predefined to sniff the PCP field.
- **Default priority:** select default priority; which will be applied to non classified incoming packets. Priority 7 is the highest. Priority 0 is the lowest.
- **TCP Ack Class in IPv4:** Mapping TCP ACK (IPv4) to a Class Value.
- **TCP Ack Class in IPv6:** Mapping TCP ACK (IPv6) to a Class Value.
- **ARP Class:** Mapping ARP to a Class Value.
- **DSCP Class:** Mapping of each DSCP value to a Class Value.

As shown above, if QoS criterion: DSCP, all other options are grayed out, and follow the QoS rules below.

According to G.9960 specs, the priority mapping recommended by [IEEE 802.1D] subclause 7.7.3 is presented in Table III.1. for four priority queues.

PCP	Priority	Acronym	Traffic Types
1	0 (Third)	BK	Background
0	1 (lowest)	BE	Best Effort
2	2 (lowest)	EE	Excellent Effort
3	3 (Third)	CA	Critical Applications
4	4 (second)	VI	Video, < 100 ms latency and jitter
5	5 (second)	VO	Voice, < 10 ms latency and jitter
6	6 (highest)	IC	Internetwork Control
7	7 (highest)	NC	Network Control

In summary, the sequence of priority queue, (7,6) > (5,4) > (3,0) > (2,1)

Chapter 9 VLAN Interface

PG-9182PT Web Configuration
Log Out

[G.hn](#)
[IP](#)
[Ethernet](#)
[Device](#)
[Multicast](#)
[QoS](#)
[VLAN](#)
[G.hn_spectrum](#)
[Log file](#)
[TR069](#)
[Advanced](#)

VLAN Configuration

VLAN feature Enabled: NO

Disable VLAN

Configure port type and tag

ETHA VLAN PVID: 0

ETHA Port configuration: NONE

ETHB VLAN PVID: 0

ETHB Port configuration: NONE

FW VLAN PVID: 0

MGMT Port configuration: NONE

SDIO VLAN PVID: 0

SDIO Port configuration: NONE

Ingress/Egress Filtering

Enable VLAN Filtering: NO

Allowed TAGS in ETHA:

0	0	0	0
0	0	0	0
0	0	0	0
0	0	0	0

Allowed TAGS in ETHB:

0	0	0	0
0	0	0	0
0	0	0	0
0	0	0	0

Allowed TAGS in FW:

0	0	0	0
0	0	0	0
0	0	0	0
0	0	0	0

Allowed TAGS in SDIO:

0	0	0	0
0	0	0	0
0	0	0	0
0	0	0	0

Submit and Enable VLAN Cancel

9.1 VLAN Configuration

VLAN configuration has been improved allowing the definition of access, trunk and hybrid VLAN ports.

- **VLAN Feature Enabled:** To activate/deactivate VLAN (IEEE 802.1Q) tagging/untagging traffic.
- **ETHA VLAN PVID:** VLAN identifier for Ethernet A port (if it is set to 0, tagging is deactivated).
- **ETHA Port configuration:** Port Configuration for Ethernet A port (ACCESS, TRUNK, NONE).
- **ETHB VLAN PVID:** VLAN identifier for Ethernet B port (if it is set to 0, tagging is deactivated).
- **ETHB Port configuration:** Port Configuration for Ethernet B port (ACCESS, TRUNK, NONE).
- **FW VLAN PVID:** VLAN identifier for Ethernet A port (if it is set to 0, tagging is deactivated).
- **MGMT Port configuration:** Port Configuration for management port (ACCESS, TRUNK, NONE).
- **SDIO VLAN PVID:** VLAN identifier for SDIO port (if it is set to 0, tagging is deactivated).
- **SDIO Port configuration:** Port Configuration for SDIO port (ACCESS, TRUNK, NONE).

Ingress/Egress Filtering

- **Enable VLAN Filtering:** To enable/disable VLAN ingress and egress filtering.
- **Allowed TAGS in ETHA:** Tags allowed on Ethernet A interface.
- **Allowed TAGS in ETHB:** Tags allowed on Ethernet B interface.
- **Allowed TAGS in FW:** Tags allowed on firmware interface.
- **Allowed TAGS in SDIO:** Tags allowed on SDIO interface.

Chapter 10 G.hn spectrum Interface

COMTREND

PG-9182PT Web Configuration

Log Out

[G.hn](#)
[IP](#)
[Ethernet](#)
[Device](#)
[Multicast](#)
[QoS](#)
[VLAN](#)
[G.hn spectrum](#)
[Log file](#)
[TR069](#)
[Advanced](#)

Notches Configuration

Notch index	Start freq (KHz)	Stop freq (KHz)	Depth (dB)	Type
0	1800	2000	100	Regulation
1	3500	4000	100	Regulation
2	7000	7300	100	Regulation
3	10100	10150	100	Regulation
4	14000	14350	100	Regulation
5	18068	18168	100	Regulation
6	21000	21450	100	Regulation
7	24890	24990	100	Regulation
8	28000	29700	100	Regulation
9	50000	54000	100	Regulation
10	0	1807	100	Regulation
11	80000	100000	100	Regulation
12	28000	30000	30	Regulation

Add new user notch

•Index (0..9)

•Start frequency (KHz)

•Stop frequency (KHz)

•Depth (0..40dB, 100 removes notch)

Remove user notch

•Index (0..9)

10.1 Notches


In this tab a table with all configured **Notches** of selected node will be shown. The table is composed of next columns for every notch: Notch Number, Type of notch, Start Frequency (KHz), Stop Frequency (KHz), Depth (in dB).

The first 13 notches (Regulation) are Read Only, **RO**, in the system and they can be neither removed nor modified. The next 40 notches (Vendor) are defined by the vendor using SDK and they are also RO. The last 10 notches (User) are R/W and they can be added/removed by user using this tool.

To add new notches the user should fill the "**Add a new User Notch**" fields, setting Start and Stop frequencies in KHz and depth in dB of notch and then press the "**Ok**" button. They will be added in first User free position from number 0 to 9. (If successful, you can see a record in the Type column)

To remove a User Notch, the "**Remove a User Notch**" section should be used, setting notch number to be removed from 0 to 9 and pressing the "**Ok**" button.

Chapter 11 Log file Interface



The screenshot shows the 'PG-9182PT Web Configuration' interface. On the left is a navigation menu with links: [G.hn](#), [IP](#), [Ethernet](#), [Device](#), [Multicast](#), [QoS](#), [VLAN](#), [G.hn spectrum](#), [Log file](#), [TR069](#), and [Advanced](#). The main content area is titled 'Log File Configuration' and contains the following settings:

- Enable Log File: A dropdown menu currently set to 'NO'.
- Data capture interval (s): A text input field containing the value '1'.
- FTP server URL: An empty text input field.
- FTP server login: An empty text input field.
- FTP server password: An empty text input field.
- Upload to server interval (min): A text input field containing the value '5'.

At the bottom right of the configuration area are 'Ok' and 'Cancel' buttons. A 'Log Out' button is located in the top right corner of the main interface.

11.1 Log File

In the **Log File** configuration the following settings can be read, and changed by clicking on the corresponding "OK" button for the selected node:

- **Enable Log File** set to YES for enabling Log File functionality in the node and set to NO for disabling it.
- **Data Capture Interval** sets the interval of time in seconds to capture data.
- **FTP Server URL** configures the url for the remote FTP server where the files will be uploaded.
- **FTP Server Login** configures the user for the FTP server.
- **FTP Server Password** configures the password for the FTP server.
- **Upload to Server Interval** sets the interval of time in minutes to send the captured file to the remote server.

Chapter 12 TR069

COMTREND

PG-9182PT Web Configuration

Log Out

[G.hn](#)
[IP](#)
[Ethernet](#)
[Device](#)
[Multicast](#)
[QoS](#)
[VLAN](#)
[G.hn spectrum](#)
[Log file](#)
[TR069](#)
[Advanced](#)

TR069 Configuration

•ACS url	<input type="text"/>
•Username	<input type="text"/>
•Password	<input type="password"/>
•PeriodicInformEnable	YES ▾
•PeriodicInformInterval	<input type="text" value="86400"/>
•Conn Req Username	<input type="text"/>
•Conn Req Password	<input type="password"/>

STUN Configuration

•STUNEnable	NO ▾
•STUNServerAddress	<input type="text"/>
•STUNServerPort	<input type="text" value="3478"/>
•STUNUsername	<input type="text"/>
•STUNPassword	<input type="password"/>
•STUNMaxKeepAlivePeriod	<input type="text" value="20"/>
•STUNMinKeepAlivePeriod	<input type="text" value="10"/>

TR069 Configuration

- **ACS url:** URL for the CPE to connect to the ACS using the CPE WAN Management Protocol. This parameter MUST be in the form of a valid HTTP or HTTPS URL. An HTTPS URL indicates that the ACS supports SSL. The "host" portion of this URL is used by the CPE for validating the certificate from the ACS when using certificate-based authentication.
- **Username:** Username used to authenticate the CPE when making a connection to the ACS using the CPE WAN Management Protocol. This username is used only for HTTP-based authentication of the CPE.
- **Password:** Password used to authenticate the CPE when making a connection to the ACS using the CPE WAN Management Protocol. This password is used only for HTTP-based authentication of the CPE.
- **PeriodicInformEnable:** When set to YES, the modem should periodically send information to the ACS using the Inform method call.
- **PeriodicInformInterval:** The duration in seconds of the interval for which the CPE MUST attempt to connect with the ACS and call the Inform method.
- **Conn Req Username:** Username used to authenticate an ACS making a Connection Request to the modem.
- **Conn Req Password:** Password used to authenticate an ACS making a Connection Request to the modem.

STUN Configuration

- **STUNEnable:** Enables(YES) or disables(NO) the use of STUN. This applies only to the use of STUN in association with the ACS to allow UDP Connection Requests.
- **STUNServerAddress:** Host name or IP address of the STUN server to send Binding Requests if STUN is enabled via STUN_ENABLE parameter. If is an empty string and STUN_ENABLE is YES, the modem should use the address of the ACS extracted from the host portion of the ACS URL.
- **STUNServerPort:** Port number of the STUN server to send Binding Requests if STUN is enabled via STUN_ENABLE. By default, this should be equal to the default STUN port, 3478.
- **STUNUsername:** If it is not an empty string, the value of the STUN USERNAME attribute to be used in Binding Requests (only if message integrity has been requested by the STUN server). If it is an empty string, the modem will not send STUN Binding Requests with message integrity.
- **STUNPassword:** The value of the STUN Password to be used in computing the MESSAGE-INTEGRITY attribute to be used in Binding Requests (only if message integrity has been requested by the STUN server).
- **STUNMaxKeepAlivePeriod:** If STUN is enabled, the maximum period, in seconds, that STUN Binding Requests must be sent for the purpose of maintaining the binding in the Gateway. This applies specifically to Binding Requests sent from the UDP Connection Request address and port. A value of -1 indicates that no maximum period is specified.
- **STUNMinKeepAlivePeriod:** If STUN is enabled, the minimum period, in seconds, that STUN Binding Requests can be sent for the purpose of maintaining the binding in the Gateway. This limit applies only to Binding Requests sent from the UDP Connection Request address and port, and only those that do not contain the BINDING-CHANGE attribute. This limit does not apply to retransmissions following the procedures defined in [RFC3489].

Chapter 13 Advanced Interface

The screenshot displays the 'PG-9182PT Web Configuration' page. On the left is a navigation menu with links: [G.hn](#), [IP](#), [Ethernet](#), [Device](#), [Multicast](#), [QoS](#), [VLAN](#), [G.hn spectrum](#), [Log file](#), [TR069](#), and [Advanced](#). The main content area has the COMTREND logo at the top left and a 'Log Out' button at the top right. Below the logo is a 'Hardware Reset' section with a 'Hardware Reset' button. Underneath is a 'Factory Reset*' section containing a 'Password' input field, a warning message '*Warning! Current configuration will be lost', and 'Ok' and 'Cancel' buttons.

Hardware Reset: Click on this button to perform a reboot in the node.

Factory Reset: Input the password: **betera** and click the **OK** button to perform a factory reset. The current configuration will be lost.